



CABIN INSTALLATION INSTRUCTIONS – SERIES 66

1. Attach the right and left front footrests (parts ① and ②) using the supplied M16 bolts, without fully tightening them.
2. If the fenders are fitted with spacers (between the fender plate and the axle), install the supplied cover panel (part ③) in the central compartment beneath the cab windscreen and secure it with the M6 screws. First remove the rubber seal, then refit it underneath the cover panel.
3. Position the cab on the fenders, making sure that the footrests fit inside the cab. Then insert the M12 bolts into the fenders and the four M8 × 60 bolts through the lower part of the cab and the footrests.
4. Fully tighten all the bolts previously fitted.
5. Install the panel behind the seat (part ④) and secure it to the rear cab crossmember using M8 screws. Fit the right-hand side cover panel next to the seat (part ⑤) and the two floor mats. If necessary, cut the rubber mat around the control levers.

CABIN WITH HEATING

Remove the plugs from the water pump and the engine cylinder head, then install the supplied fittings. Connect the rubber hoses and secure them with the hose clamps.

Remove the radiator cap and run the engine until the cooling circuit is filled, remembering to open the valve on the heater as well.

Top up the engine coolant to the correct level and refit the radiator cap.

